
MAZDA MOTORSPORTS




MAZDA MOTORSPORTS

PENSKE

SPEC MIATA FRONT SHOCK

(COILOVER VERSION)



LOWER NUT

1 1/4" (32mm) Torque 50ft-lbs (68 N-m) Apply 243 Loctite to threads

OEM MOUNTING PLATE- NC10-28-340C

Not included in kit – follow mount modification instructions below prior to reassembly

BELLEVILLE WASHERS (3 QTY)

To be stacked with base of cone oriented against the upper mount. See cross section view for example.

UPPER NUT

SHIM SPACER


Provides hard durable surface for Belleville washers.


10mm ID MONOBALL

Eliminates side load on shaft as opposed to fixed stud mounting styles.

MOUNTING NUT SPACER

Install on end of shaft before threading Nyloc jam nut (damper is delivered with this nut threaded on end of shaft)





TOP MOUNT MODIFICATION:

- 1. Remove mount from vehicle
- 2. Secure mount to table of drill press/mill
- 3. Using high speed step drill bit & cutting fluid, enlarge existing thru hole to Ø.938 (15/16"). (Step drill can be purchased from any industrial supplier such as McMaster-Carr, MSC, Grainger, etc.)
- 4. Chamfer/deburr hole edges
- Assemble mounting components as specified above
- Re-install into vehicle



RACING SHOCKS.

150 FRANKLIN ST • P.O. BOX 1056 READING, PA 19602

(610) 375-6180 • (610) 375-6190 FAX