

# MAZDA MOTORSPORTS

## Installation Instructions



Mazda Miata  
Penske Rear Shock Spacer  
1999-2005  
PN: 0000-04-5294

# Penske Rear Shock Spacer

*\*The Penske lower shock bushings will not be used with this product. Set them aside.*

1. Slide large tapered spacer over the threaded shock mount stud in the upright. (Pic 1)
2. Slide Penske rear shock over the threaded shock mount stud in the upright.
3. Slide small spacer through the lower shock mount onto the threaded shock stud mount in the upright.
4. Put supplied washer over the supplied bolt.
5. Put Blue loctite on threads of bolt.
6. Install bolt/washer combo into upright.
7. Torque to 70 ft lbs.

