

MAZDA MOTORSPORTS

Installation Instructions

2006-2015 Mazda Miata Stainless Steel Clutch Line

1. Insert straight adaptor into clutch master cylinder. (Image 1)
2. Fit 90 degree end of the stainless clutch line to the adaptor installed in the clutch master cylinder.
3. Route clutch line behind brake master cylinder.
4. Use supplied nylock nut and clamp to secure the clutch line to the existing stud on the firewall. (Image 3)
5. Route line down from firewall to clutch slave cylinder.
6. Install straight adaptor into clutch slave cylinder. (Image 2)
7. Install 90 degree fitting to straight adaptor in clutch slave cylinder (Image 2).
8. Install straight end of clutch line to 90 degree fitting attached to clutch slave cylinder. (Image 2)
9. Tighten all fittings.
10. Use supplied zip ties to secure the clutch line from the firewall down to the clutch slave cylinder.

SEE BACK FOR IMAGES.

