

# MAZDA MOTORSPORTS

## Installation Instructions



Spec MX-5 Shock Hats  
2006-2015

# Shock Hats

1. Thread supplied bolts into the shock hat using Loctite Red thread locker.

2. Insert spherical bearing into the large nut.

3. Put anti seize on the bottom of the threads of the large 1.5" nut.

4. Thread nut/spherical combo into shock hat and make it hand tight.

5. Wipe away any excess anti-seize.

6. Use 1 1/4" socket and torque to 85 ft./lbs.

7. Once torqued, mark the nut and housing with a new paint mark to monitor any movement of the nut. Periodically check for movement throughout the racing season.

8. Refer to Penske cut away for shock to shock hat install instructions.

