

1  
9  
3

TUNE-UP			COOLING SYSTEM & BELTS		
Item	Part Number	Remarks	Item	Part Number	Remarks
Spark Plug	B601-18-110 <AN> <b>0000-18-B601</b>	BPR5ES-11 (Fed)	Water Pump	8AB7-15-010 <C> <b>B621-15-116A</b>	
	BP01-18-110 <AN> <b>0000-18-BP01</b>	BKR5ES-11 (Std)	Water Pump Gasket	B621-15-116A <AN> <b>B6BF-15-116</b>	
Rotor	F220-18-V05A <AN> <b>F220-18-V05B</b>		Thermostat	8AN1-15-171 <AN> <b>8AK1-15-171</b>	
Cap	G609-18-V00 <A> <b>F220-18-V00A</b>		Thermo Gasket	B621-15-173	
Plug Wire Set	0000-18-119A		Radiator Hose	B366-15-186A	Upper
Ignition Coil	B6S7-18-10XA			B366-15-185A	Lower
Igniter	BP01-18-251		Radiator Cap	F807-15-205	M/T
EGI Control Box	B61K-18-881R	Reman.		<AN> <b>F8B7-15-205</b>	
Air Filter	B6S7-13-Z40 <AN> <b>B6S7-13-Z40 -9U</b>		Fan & Alternator Belt	D316-15-205	A/T
Fuel Filter	BP01-20-490A <AN> <b>BP01-13-480 -9U</b>			B6S7-18-381B <AN> <b>B6S7-18-381B-9U</b>	
Oil Filter	B6Y1-14-302 <AN> <b>B6Y2-14-302</b>		P/S Belt	B366-15-907	w/o A/C, w/ P.S.
PCV Valve	B541-13-890A			<AN> <b>B660-15-908</b>	
				B366-15-909	w/ A/C
				<AN> <b>B66S-15-909J</b>	
				B366-15-908A	w/ A/C, w/o P.S.
			Fan	FEH5-15-140	
			Fan Drive	B61H-15-150A	

### BRAKES & WHEEL BEARINGS

Item	Part Number	Remarks
Brake Shoe Set	B5Y7-26-38Z	Rear
Pad Set	B5Y6-33-28Z <A> <b>BCYW-33-28ZA-9F</b>	Front
Front Pad Attachment	B455-33-29Z <AN> <b>B4Y5-33-29Z</b>	Front
Brake Drum	B596-26-251A <AN> <b>D102-26-251</b>	Rear
Brake Rotor	BR70-33-25X <A> <b>BR70-33-25XF</b>	Front
Wheel Bearing	B455-33-047B <AN> <b>B455-33-047C</b>	Front
Oil Seal	G304-33-065	Front
Front Wheel Hub	B455-33-061 <A> <b>B01A-33-060A</b>	
Rear Wheel Hub	B455-26-15XA	
Caliper Assembly (R)	B462-33-980B <A> <b>B4Y2-33-98ZR</b>	Front
Caliper Assembly (L)	B462-33-990B <A> <b>B4Y2-33-99ZR</b>	Front
Caliper Seal Kit	B4Y5-33-24Z	Front
Wheel Cylinder	GJ21-26-610C <AN> <b>GJ21-26-610D</b>	Rear
Wheel Cylinder Kit	B216-26-03Z	Rear
Master Cylinder	BR70-43-400C <A> <b>BR70-43-400D</b>	M/T
	BR72-43-400C	A/T
	<C> <b>BR70-43-400D</b>	
Master Cylinder Kit	BW0A-43-61Z	
Brake Hose	B455-43-980 <AN> <b>B455-43-980B</b>	

### CLUTCH PARTS

Item	Part Number	Remarks
Clutch Disc	B504-16-460B <A> <b>B504-16-460D-9U</b>	
Clutch Cover	B505-16-410 <AN> <b>B505-16-410C-9U</b>	
Release Collar	B315-16-510	
Master Cylinder	BR70-41-990 <A> <b>BR70-41-990A</b>	
Master Cylinder Kit	B312-41-52Z	
Release Cylinder	B455-41-920	
Release Cylinder Kit	FB01-49-460	
Clutch Pilot Bearing	F801-11-303	M/T

### DIFFERENTIAL

Item	Part Number	Remarks
Pinion Seal	F003-27-238A <AN> <b>F003-27-238B</b>	A/T
	F001-27-238	M/T
	<A> <b>F003-27-238B</b>	
Diff. Side Bearing	F001-27-350	
Trans. Filter	FU61-21-500B	A/T
Trans. Gasket	FU60-21-512B	

### ELECTRICAL

Item	Part Number	Remarks
Alternator	B366-18-300R <AN> <b>B366-18-300R-00</b>	Reman.

ELECTRICAL—Cont'd			ENGINE PARTS—Cont'd		
Item	Part Number	Remarks	Item	Part Number	Remarks
Regulator	B366-18-W70		Oil Pump	B3C7-14-100B	
Starter	B676-18-400R	Reman.		<A> <b>B35J-14-100</b>	
	<AN> <b>B676-18-400R-00</b>		Ring Gear	B367-11-502	
	B6S8-18-400R	M/T Cal.	Flywheel	B541-11-500	
	<AN> <b>B6S8-18-400R-00</b>		Oil Filler Cap	8871-10-250A	
Starter Clutch	B630-18-X45			<AN> <b>0453-10-250A</b>	
Starter Solenoid	E356-18-X10	Fed.	Oil Cap Gasket	8871-10-252	
	FE1J-18-X10	Cal.	Intake Manifold Gasket	B61K-13-111	Fed.
Ignition Switch	B455-66-151			B3C7-13-111	Cal.
	<AN> <b>B455-66-151A</b>		Exhaust Manifold Gasket	B61K-13-460A	Fed.
Emission Ctrl. Switch	BP03-18-861B	Oxygen Sensor		B3C7-13-460	Cal.
Oil Pressure Switch	B367-18-501		Camshaft Oil Seal	BP01-10-602	
Battery	0000-80-126F			<AN> <b>BP01-10-602A</b>	
			Crankshaft Oil Seal	BP05-11-312	
			Oil Pan Gasket	B541-10-427	
				B541-10-428	
ENGINE PARTS			FUEL & EXHAUST SYSTEMS		
Item	Part Number	Remarks	Item	Part Number	Remarks
Engine Gasket Set	8CB1-10-271		Fuel Pump	B3E7-13-350	Pump Only
Valve Grind Set	8AB4-10-235			<A> <b>B6BF-13-350</b>	
	<AN> <b>8AB4-10-235A</b>			B3E7-13-35ZB	Assembly
Head Gasket	B61L-10-271	Fed.	Gas Cap	GN60-42-250	
	B64D-10-271	Cal.	Front Pipe	BP04-40-500A	
	<AN> <b>B64D-10-271A</b>			<A> <b>BP04-40-500B</b>	
Valve Cover Gasket	B366-10-235		Catalytic Cnvr.	B6Y5-20-600	Fed.
	<AN> <b>B366-10-235B</b>			B6BB-20-600	Cal.
Valve Guide (R)	B6Y1-10-281	Fed.	Main Silencer	BP05-40-100G	
	B6Z0-10-280	Cal.	Pre-Silencer	B691-40-300	
Valve Guide (L)	B6Y0-10-290	Fed.	Exhaust Gasket	B322-40-305	
	B6Z0-10-290	Cal.		B323-40-305	
Valve Seal	B630-10-155	Fed.	Rubber Hanger	RF03-40-061	
	B660-10-155	Cal.			
	<AN> <b>KL02-10-155</b>				
Intake Valve	B630-12-111	Fed.	LIGHTING		
	B541-12-111	Cal.	Item	Part Number	Remarks
Exhaust Valve	B630-12-121	Fed.	Brake & Tail Bulb	0000-11-1157	
	B541-12-121	Cal.	Turn Signal Bulb	0000-11-1156	
Valve Spring	B675-12-125	Fed.	Back-Up Bulb	0000-11-1157	
	B366-12-125	Cal.	License Plate Bulb	0000-11-0168	
Rocker Arm	B308-12-130A	Fed.	Side Clearance Bulb	0000-11-0921	
	B541-12-130	Cal.	High Mt. Brake Bulb	0000-11-0921	
	B308-12-150A	Fed.	Dome Light Bulb	0000-11-3175	
	B541-12-150	Cal.		<A> <b>9970-05-080L</b>	
Camshaft	B675-12-420B	Fed.	Headlamp Bulb	0000-11-9004-90	
	B62A-12-420A	Cal.			
Cam Sprocket	B366-12-425		SHOCKS & STEERING		
Timing Belt	BP01-12-205A		Item	Part Number	Remarks
	<A> <b>BPY1-12-205</b>		Front Shock (R)	B455-34-700D	
Tensioner	B630-12-700D			<AN> <b>BR70-34-700F</b>	
	<AN> <b>B630-12-700E</b>				
Ring Set	B6Y0-11-SC0A	Fed.			
	B6Y6-11-SC0A	Cal.			
Main Bearing Set	B6Y2-11-SG0				
Rod Bearing Set	B6Y0-11-SE0				

### SHOCKS & STEERING—Cont'd

Item	Part Number	Remarks
Front Shock (L)	B455-34-900D <A> <b>BR70-34-900F</b>	
Rear Shock (R)	B455-28-700	
Rear Shock (L)	B455-28-900	
Lateral Link (R)	BR70-28-620	
Lateral Link (L)	BR70-28-630	
Tie Rod End	8AB2-32-280	
Lower Arm (R)	BR70-34-300B	
Lower Arm (L)	BR70-34-350B	
Ctrl. Arm Bushing (R)	B455-34-46XA <A> <b>BTAA-34-46X</b>	
Ctrl. Arm Bushing (L)	B455-34-46YA <AN> <b>BTAA-34-46Y</b>	
Trailing Link (R)	BR70-28-200B	
Trailing Link (L)	BR70-28-250	
Ball Joint	B455-34-550	

### WIPERS & WASHERS

Item	Part Number	Remarks
Wiper Blade (R)	BR72-67-330 <AN> <b>NC11-67-330 -9U</b>	
Wiper Blade (L)	BR70-67-330A <AN> <b>BR70-67-330C</b>	
Wiper Insert (R)	BR72-67-331 <AN> <b>D040-67-333 -9U</b>	
Wiper Insert (L)	BR70-67-331 <AN> <b>B460-67-333</b>	
Wiper Arm (R)	BR71-67-321	
Wiper Arm (L)	BR70-67-321	
Washer Nozzle	BS06-67-510	
Washer Pump	S084-76-672	